

WASHER

Repair Parts List

MODEL NUMBER
MFR30PDCTS

When requesting service or ordering parts, always provide the following information:


- Product Type
- Part Number
- Model Number
- Part Description

MAYTAG®

©2005 Maytag Services

Section: BASE FRAME

Model: MFR30PDCTS




21-Nov-05
520 780A

CW19-45

Section: CABINET (PD)

Model: MFR30PDCTS




21-Feb-05
520 785

CW12-50

Section: TOP COVER ASSEMBLY

Model: MFR30PDCTS




12-Sep-05
520 787A

CW13-24

Section: DOOR LOCK ASSEMBLY

Model: MFR30PDCTS




21-Feb-05
521 450

CW10-78

Section: DOOR

Model: MFR30PDCTS




23-Sep-05
519 389A

CW10-77

Section: SOAP BOX, DRAIN & HOSE ASSEMBLY

Model: MFR30PDCTS




24-Feb-05
520 788

CW16-30

Section: CONTROL PANEL (PD)

Model: MFR30PDCTS




23-Feb-05
520 784

CW11-94

Section: COIN VAULT (PD)

Model: MFR30PDCTS




23-Feb-05
520 789

CW11-96

Section: BASKET & OUTER SHELL ASSEMBLY

Model: MFR30PDCTS




22-Feb-05
520 781

CW24-03

Section: MOTOR & BASKET PULLEY

Model: MFR30PDCTS




23-Feb-05
520 783

CW23-05

Section: WATER VALVE & REAR PANEL

Model: MFR30PDCTS



10-Feb-05
520 788

CW22-03